



Maury Microwave

## User Guide

# Precision N 75 Ohm Coaxial Calibration Kit

Models: 8880CK10/11





---

# **User Guide**

# **Precision N 75 Ohm Coaxial Calibration Kit**

**Models: 8880CK10/11**



2900 Inland Empire Boulevard  
Ontario, California 91764-4804 USA  
Telephone: (909) 987-4715  
Facsimile: (909) 987-1112

[maurymw.com](http://maurymw.com)



## ***Warranty***

Maury Microwave hardware products are warranted against defects in materials and workmanship for a period of one year from date of shipment. During the warranty period, Maury Microwave will, at its option, either repair or replace products which prove to be defective.

Maury Microwave software products are warranted against defects in material and workmanship of the media on which the product is supplied for a period of ninety (90) days from date of shipment. Maury also warrants that the product shall operate substantially in accordance with published specifications during the same warranty period. During the warranty period, Maury Microwave will, at its option, either repair or replace products which prove to be defective. Maury does not warrant that the operation of the product shall be uninterrupted or error-free.

For warranty service or repair, all products must be returned to Maury Microwave and must be issued a return authorization number by Maury prior to shipment. Buyer shall prepay shipping charges to Maury. Obligation is limited to the original Buyer.

## ***Limitation of Warranty***

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or wear resulting from normal use. No other warranty is expressed or implied. Maury Microwave specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

The remedies provided herein are the Buyer's sole and exclusive remedies. Maury Microwave shall not be liable for any direct, indirect, special, incidental, or consequential damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or any other financial loss) arising out of the Buyer's use of or inability to use the product, even if Maury or an authorized Maury dealer has been advised of the possibility of such damages.

---



**General Information ..... 1**

- Calibration Kit Description ..... 1*
- Maintenance ..... 1*
- Calibration ..... 1*
- Supporting Test Port Adapters ..... 1*
- Electrostatic Discharge Precautions ..... 1*
- Connector Description ..... 2*
- Connector Care ..... 2*
- Connector Tightening ..... 3*
- Calibration Kit Contents ..... 4*

**Standard Definitions ..... 5**

- Anritsu Network Analyzers ..... 5*
- Keysight Network Analyzers ..... 6*
- Rohde & Schwarz Network Analyzers ..... 7*

**Appendix ..... 9**

- Data Sheet Resources ..... 9*

**Contacts ..... 11**

## Tables

---

Table 1. Male Standard Definitions for Anritsu.....	5
Table 2. Female Standard Definitions for Anritsu.....	5
Table 3. Standard Definitions for Keysight.....	6
Table 4. Standard Definitions for Rohde & Schwarz.....	7

## Figures

---

Figure 1. Using the Torque Wrench .....	3
---	---



### ***Calibration Kit Description***

This series of Precision N 75 Ohm coaxial calibration kits is designed to provide accurate calibrations of network analyzers in the DC to 2.0 GHz range. However, these kits can be used at higher frequencies. Each of these kits includes all the necessary calibration standards and associated hardware needed for the accurate calibration of most network analyzers.

**NOTE:** This document, calibration constants software, and data sheet can be downloaded from our website: [maurymw.com](http://maurymw.com)

**NOTE:** Legacy analyzer software is not on our website but is available for purchase.

### ***Maintenance***

This calibration kit is relatively maintenance free if the components are handled with the same care that is appropriate to all precision equipment. As with any precision component, proper care should be taken to assure clean mating surfaces, correct alignment when mating, and proper torquing of connectors or waveguide coupling screws. To help maintain the integrity of the components in this kit, routine visual inspection and cleaning of mating surfaces is recommended. Failure to do so may result in degraded repeatability and accuracy, as well as damage any mated devices.

### ***Calibration***

To maintain verification that a calibration kit is performing to traceable specifications, we recommend that all kits be periodically returned to Maury Microwave for calibration. The typical calibration cycle is one year, although actual need may vary depending on usage.

### ***Supporting Test Port Adapters***

When configuring a test setup, be sure that damaging stresses are not applied to the connectors on the test set. This is particularly critical when the attached components are heavy or long. Always properly support the test port adapters being used.

### ***Electrostatic Discharge Precautions***

Protection against electrostatic discharge (ESD) is essential while inspecting, cleaning, or making connections to connectors attached to a static-sensitive circuit, such as those found inside test sets.

When handling the connectors on the test set, be aware that you are coming in contact with exposed center conductors that are connected directly to the static-sensitive internal circuits of the network analyzer. Make sure that you and your equipment are well-grounded before inspecting, cleaning, or making connections to test set ports. Standard ESD precautions, such as the use of grounded wrist straps and grounded antistatic mats, are recommended.

## **Connector Description**

All calibration standards and adapters in this series of kits utilize the Maury Microwave Precision N 75 Ohm Connector, which is compliant with IEC169-16.

## **Connector Care**

Precision connectors must be handled carefully if accurate calibrations and measurements are to be obtained. All connectors should be inspected prior to each use. For optimum measurement results, all interfaces should be visually inspected under magnification and cleaned on a regular basis. Proper connector contact pin depths should also be verified through regular inspections using a connector gage, such as the Maury Microwave A020G connector gage kit, to insure that the connectors on both calibration devices and devices under test (DUTs) have contact pin depths within recommended tolerances. Refer to Maury data sheet **5E-054** (available on our website) for proper pin depth specifications.

Care should be used whenever aligning connectors. Tighten connector coupling nuts using an appropriate torque wrench while holding the opposing connector with an open-end wrench.

When disconnecting devices, take care not to rock or bend any of the connections. Disconnect devices by disengaging the coupling nuts and gently pulling the connectors apart in a straight line.

Always use protective covers on all connectors when devices are not in use.

Should a connector become damaged, it should be repaired before it is used any further or replaced immediately. A damaged connector can damage other mated connectors.

**CAUTION:** Do not mate Type N 75 ohm connectors to Type N 50 ohm connectors. Mating a Type N 75 ohm female connector to a Type N 50 ohm male connector will destroy the contact on the Type N 75 ohm female connector. Mating a Type N 75 ohm male connector to a Type N 50 ohm female connector will not provide proper electrical contact for the center conductors.

## Connector Tightening


Damage to a calibration device or attaching connector can occur if the device is turned instead of the connector nut. ALWAYS turn the nut when making connections. Never turn the device itself.

Always use a torque wrench (Maury model **2698C2**) to final-tighten all connections. This will insure calibration accuracy and measurement repeatability.

When making connections, a **3/4 inch** open-end wrench may be required to hold the body of one device stationary while torquing the nut on the other device or cable. This open-end wrench is supplied with this calibration kit for this purpose.

Using the torque wrench, hand-tighten the connection to be torqued by holding the calibration device steady and turning only the nut.

- Hold the torque wrench with your thumb and index finger, behind the groove in the handle (see **Figure 1**).
- Tighten the connection until the ball in the handle crests on the cam (as the handle begins to break). Do not “fully break” the handle of the torque wrench to reach the specified torque.
- Reverse the previous procedure to disconnect the connection.



**Figure 1.** Using the Torque Wrench

**Calibration Kit Contents****Standard Components – 8880CK10**

---

1 ea	Short, female	8884A
1 ea	Short, male	8884B
1 ea	Open, female	8885A
1 ea	Open, male	8885B
1 ea	Fixed Termination, female	8883A
1 ea	Fixed Termination, male	8883B
1 ea	Case Assembly	

**Standard Components – 8880CK11**

---

1 ea	Short, female	8884A
1 ea	Short, male	8884B
1 ea	Open, female	8885A
1 ea	Open, male	8885B
1 ea	Fixed Termination, female	8883A
1 ea	Fixed Termination, male	8883B
1 ea	Adapter, male to male	8882B
1 ea	Adapter, female to male	8882C
1 ea	Adapter, female to female	8882A
1 ea	Case Assembly	

## Standard Definitions

### Anritsu Network Analyzers

**Table 1.** Male Standard Definitions for Anritsu

Type N Male Open Device	
C0	23.75 e-15
C1	3500.0 e-27
C2	-675.0 e-36
C3	40.0 e-45
Offset Length	0.5283 cm
Serial Number	00000

Type N Male Short Device	
Offset Length	0.5283 cm
Serial Number	00000

**Table 2.** Female Standard Definitions for Anritsu

Type N Female Open Device	
C0	-100.0 e-15
C1	-225.0 e-27
C2	350.0 e-36
C3	0.1 e-45
Offset Length	0.0 cm
Serial Number	00000

Type N Female Short Device	
Offset Length	0.0 cm
Serial Number	00000

For specific loading instructions, see **Anritsu loading instructions**, which can be downloaded from our website: [maurymw.com](http://maurymw.com).

Keysight Network Analyzers

Table 3. Standard Definitions for Keysight

Type	Standard <sup>(1)</sup> Description	C0 x10 <sup>-15</sup> F		C1 x10 <sup>-27</sup> F/Hz		C2 x10 <sup>-36</sup> F/Hz <sup>2</sup>		C3 x10 <sup>-45</sup> F/Hz <sup>3</sup>		Fixed or Sliding <sup>(2)</sup>	Offset			Frequency GHz		Coax or W/G	Standard Label
		L0 x10 <sup>-12</sup> H	L1 x10 <sup>-24</sup> H/Hz	L2 x10 <sup>-33</sup> H/Hz <sup>2</sup>	L3 x10 <sup>-42</sup> H/Hz <sup>3</sup>	Delay ps	Z <sub>0</sub> <sup>(3)</sup> Ω	Loss <sup>(4)</sup> GΩ/s	Min		Max						
Short	Female Short	0.0	0.0	0.0	0.0						0.0	75	1.13	0.0	999.0	Coax	8884A
Open	Female Open	-100.0	-225.0	350.0	0.1						0.0	75	1.13	0.0	999.0	Coax	8885A
Load	Broadband Female Load								Fixed		0.0	75	1.13	0.0	999.0	Coax	8883A BB
Thru	Thru										0.0	75	1.13	0.0	999.0	Coax	Thru <sup>(5)</sup>
Short	Male Short	0.0	0.0	0.0	0.0						17.622	75	1.13	0.0	999.0	Coax	8884B
Open	Male Open	23.75	3500.0	-675.0	40.0						17.622	75	1.13	0.0	999.0	Coax	8885B
Load	Broadband Male Load								Fixed		0.0	75	1.13	0.0	999.0	Coax	8883B BB

<sup>(1)</sup> Open, short, load, delay/thru, or arbitrary impedance.

<sup>(2)</sup> Load or arbitrary impedance only.

<sup>(3)</sup> Z<sub>0</sub> normalized.

<sup>(4)</sup> Skin loss factor, normalized at 1 GHz.

<sup>(5)</sup> Test ports connected directly.

For specific loading instructions, see **Keysight loading instructions**, which can be downloaded from our website: [maurymw.com](http://maurymw.com)

## Rohde &amp; Schwarz Network Analyzers

**Table 4.** Standard Definitions for Rohde & Schwarz

Short (M) Min Freq = 0 Hz Max Freq = 4 GHz Length = 5.283 mm Loss = 0.0023 dB/ $\sqrt{\text{GHz}}$	Match (M) Min Freq = 0 Hz Max Freq = 4 GHz
Short (F) Min Freq = 0 Hz Max Freq = 4 GHz Length = 0 mm Loss = 0.0 dB/ $\sqrt{\text{GHz}}$	Match (F) Min Freq = 0 Hz Max Freq = 4 GHz
Open (M) Min Freq = 0 Hz Max Freq = 4 GHz Length = 5.283 mm Loss = 0.0023 dB/ $\sqrt{\text{GHz}}$ C0 = 23.75 fF C1 = 3.5 fF/GHz C2 = -0.675 fF/GHz <sup>2</sup> C3 = 0.04 fF/GHz <sup>3</sup>	
Open (F) Min Freq = 0 Hz Max Freq = 4 GHz Length = 0 mm Loss = 0.0000 dB/ $\sqrt{\text{GHz}}$ C0 = -100 fF C1 = -0.225 fF/GHz C2 = 0.35 fF/GHz <sup>2</sup> C3 = 0.0001 fF/GHz <sup>3</sup>	

For specific loading instructions, see **Rohde & Schwarz loading instructions**, which can be downloaded from our website: [maurymw.com](http://maurymw.com).

(This page intentionally left blank)



***Data Sheet Resources***

2Z-061A – Type N 75 ohm Calibration Kit  
<http://maurymw.com/pdf/datasheets/2Z-061A.pdf>

5E-054 – Precision Type N 75 ohm Connectors  
<http://maurymw.com/pdf/datasheets/5E-054.pdf>

2Y-001 – Connector Gage Summary  
<http://maurymw.com/pdf/datasheets/2Y-001.pdf>



**Corporate**

Maury Microwave Corporation  
2900 Inland Empire Boulevard  
Ontario, California 91764-4804  
United States of America

Tel. 909-987-4715  
Fax 909-987-5855  
Email [maury@maurymw.com](mailto:maury@maurymw.com)

**Sales**

Tel. 909-204-3224  
Fax 909-987-1112  
Email [maury@maurymw.com](mailto:maury@maurymw.com)

**Customer Support**

Tel. 909-204-3283  
Fax 909-987-1112  
Email [support@maurymw.com](mailto:support@maurymw.com)

**Website** [maurymw.com](http://maurymw.com)

**Web Resources**

Maury Calibration Kits  
[http://maurymw.com/Precision/VNA\\_Cal\\_Kits.php](http://maurymw.com/Precision/VNA_Cal_Kits.php)

Maury Precision Coaxial and Waveguide-to-Coaxial Adapters  
[http://maurymw.com/Finder/Adapter\\_Finder.php](http://maurymw.com/Finder/Adapter_Finder.php)

Maury Applications Notes Library & Technical Articles Archive  
<http://maurymw.com/Support/tech-support.php>

Maury Sales Representative Finder  
<http://maurymw.com/Support/find-sales-rep.php>

***Visit our website for additional product information and literature.***